VELCRO

See other installation options using Silicone or Instant Adhesive or VHB Tape

We do not offer our safety padding with PSA (Pressure Sensitive or Peel/Stick Backing).

Velcro is best where the customer needs to be able to remove and re-attach the safety padding.

 You will need instant adhesive/superglue to attach theVelcro to the padding

1. Mark the location of where you will place the Velcro on the target surface
2. Mark the "matching" location on the padding where you will place the Velcro
   - this is so that the 2 strips of Velcro will match up
3. Attach one side of Velcro "HOOK" strip to the surface that will be padded.
   - usually already has peel/stick backing
4. Apply instant adhesive to the back of the Velcro "LOOP" strip that will go on the padding
   - this is because the standard adhesive on the Velcro will "not" stick to the padding
5. Attach the LOOP strip to the padding - allow adhesive to set
6. Now you can attach and remove the padding whenever you need

Silicone Solution - *For most applications*
• Silicone provides heavy duty adhesion
• With silicone, you can add a bead around the outer edge to seal off from dirt/liquids/tampering
• Silicone will adhere to virtually any surface including rough textures like brick

Instant Adhesive - *For many applications*
• Instant Adhesive is like "Superglue"
• Great for very strong/permanent bonding
• Best for applying to smooth surfaces

VHB Tape Solution - *For installation where liquid adhesive is not an option*
• This is the "only" tape we found that will stick to both our products and most other surfaces
• Tape needs 72 hours to set for **maximum adhesion**
• Tape is expensive relative to silicone
• We do not attach the tape for you
• We cannot cut the tape and re-spool into smaller rolls

Boing product warranty is voided if non-approved adhesive is used

Effective 1 January 2012

Network USA Inc. Companies
136 Walker Street, Atlanta GA 30313
TEL 404-521-9054   ORDER: 800-477-6434   FAX: 404-222-8366
wwwBoingSafety.com   info@BoingSafety.com